



# Flue Clearances from Combustible or Flammable Material

**When installing a pizza oven, especially one that uses wood or gas, ensuring proper clearance from combustible materials such as walls, posts, ceiling or plants, is crucial for safety.**

The flue must have sufficient clearance from any combustible materials to prevent the risk of fire. We recommend a clearance of approximately 750mm for single skin flues, 75mm for Double skin and 50mm for Triple skin. For under cover pizza oven installations where the ceiling is made of combustible materials, we recommend a double or triple skin flue kit to go through the ceiling and cavity (if any).

## Installation Tips:

- **Consult Professionals:** It's advisable to engage a licenced plumber to ensure that the installation meets all safety standard and is compliant with the local council laws in your area.
- **Regular Inspection:** we recommend that you regularly check around the oven for any signs of heat damage.

By following these guidelines and local regulations, you can ensure the safe and efficient operation of your pizza oven.

